



# **VMBGP1**

# **VMBGP2**

# **VMBGP4**

**One, two or four touch buttons  
module for VELBUS system**

Binary format:

<SOF-SID10...SID0-RTR-IDE-r0-DLC3...0-DATABYTE1...DATABYTE<sub>n</sub>-CRC15...CRC1-CRCDEL-ACK-ACKDEL-EOF7...EOF1-IFS3...IFS1>

<i>bits</i>	<i>Description</i>
SOF	Start Of Frame (always 0)
SID10 & SID9	Priority (00: highest ... 11: lowest priority)
SID8...SID1	Address
SID0	Always 0
RTR	Remote Transmit Request
IDE	Identifier Extension (always 0)
r0	reserved (always 0)
DLC3...DLC0	Data Length Code (0...8)
Databyte1	Command
Databyte2	Parameter
Databyte3	Parameter
Databyte4	Parameter
Databyte5	Parameter
Databyte6	Parameter
Databyte7	Parameter
Databyte8	Parameter
CRC15...CRC1	Cyclic Redundancy Checksum
CRCDEL	CRC Delimiter (always 1)
ACK	Acknowledge slot (transmit 1 readback 0 if received correctly)
ACKDEL	Acknowledge Delimiter (always 1)
EOF7...EOF1	End Of Frame (always 1111111)
IFS3...IFS1	InterFrame Space (always 111)

*The module can transmit the following messages:*

- Channel status
- Module status
- Module type and subtype
- Bus error counter status
- First, second and third part of the channel names
- Memory data
- Memory data block (4 bytes)
- Real-time clock status
- Date status
- Daylight savings status
- Real-time clock status request
- Clear linked push button led
- Set linked push button led
- Slow blink linked push button led
- Fast blink linked push button led

*The module can receive the following commands:*

- Linked push button status
- Module type request
- Module status request
- Channel name request
- Clear channel led
- Set channel led
- Slow blink channel led
- Fast blink channel led
- Very fast channel led
- Update channel leds
- Read memory data
- Read memory data block (4 bytes)
- Memory dump request
- Write memory data
- Write memory data block (4 bytes)

- Bus error counter status request
- Real-time clock status request
- Set real-time clock
- Set date
- Set daylight savings
- Enable/disable global sunrise/sunset related actions
- Enable/disable local sunrise/sunset related actions
- Set local alarm clock
- Set global alarm clock
- Lock channel
- Unlock channel
- Disable channel program
- Enable channel program
- Select program

**Transmits real time clock status request:**

SID10-SID9 = 11 (lowest priority)  
SID8...SID1 = H'00'  
RTR = 0  
DLC3...DLC0 = 1 databyte to send  
DATABYTE1 = COMMAND\_REALTIME\_CLOCK\_STATUS\_REQUEST (H'D7')

**Transmits the real time clock status:**

SID10-SID9 = 11 (lowest priority)  
SID8...SID1 = Module address  
RTR = 0  
DLC3...DLC0 = 4 databytes to send  
DATABYTE1 = COMMAND\_REALTIME\_CLOCK\_STATUS (H'D8')  
DATABYTE2 = Day

Contents	Day
0	Monday
1	Tuesday
2	Wednesday
3	Thursday
4	Friday
5	Saturday
6	Sunday

DATABYTE3 = Hour (0...23)  
DATABYTE4 = Minute (0...59)

**Transmits the date status:**

SID10-SID9 = 11 (lowest priority)  
SID8...SID1 = Module address  
RTR = 0  
DLC3...DLC0 = 5 databytes to send  
DATABYTE1 = COMMAND\_DATE\_STATUS (H'B7')  
DATABYTE2 = Day (1...31)  
DATABYTE3 = Month (1...12)  
DATABYTE4 = High byte of Year  
DATABYTE5 = Low byte of Year

**Transmits the daylight savings status:**

SID10-SID9 = 11 (lowest priority)  
SID8...SID1 = Module address  
RTR = 0  
DLC3...DLC0 = 2 databytes to send  
DATABYTE1 = COMMAND\_DAYLIGHT\_SAVING\_STATUS (H'AF')  
DATABYTE2 = 0 =disabled / 1 = enabled

**Transmits the channel switch status:**

SID10-SID9 = 00 (highest priority)  
SID8...SID1 = Module address  
RTR = 0  
DLC3...DLC0 = 4 databytes to send  
DATABYTE1 = COMMAND\_PUSH\_BUTTON\_STATUS (H'00')  
DATABYTE2 = Channel just pressed  
DATABYTE3 = Channel just released  
DATABYTE4 = Channel long pressed

**Transmits the sensor output switch status:**

SID10-SID9 = 00 (highest priority)  
SID8...SID1 = Subaddress  
RTR = 0  
DLC3...DLC0 = 4 databytes to send  
DATABYTE1 = COMMAND\_OUTPUT\_STATUS (H'00')  
DATABYTE2 = Output channel just activated (1 = just activated)

Contents	Output channel
xxxxxxx1	Heater just activated
xxxxxx1x	Boost heater/cooler just activated
xxxxx1xx	Pump just activated
xxxx1xxx	Cooler just activated
xxx1xxxx	Temperature alarm 1 just activated
xx1xxxxx	Temperature alarm 2 alarm activated
x1xxxxxx	Temperature alarm 3 just activated
1xxxxxxx	Temperature alarm 4 alarm activated

DATABYTE3 = Outputs just deactivated (1 = just deactivated)

Contents	Output channel
xxxxxxx1	Heater just deactivated
xxxxxx1x	Boost heater/cooler just deactivated
xxxxx1xx	Pump just deactivated
xxxx1xxx	Cooler just deactivated
xxx1xxxx	Temperature alarm 1 just deactivated
xx1xxxxx	Temperature alarm 2 alarm deactivated
x1xxxxxx	Temperature alarm 3 just deactivated
1xxxxxxx	Temperature alarm 4 alarm deactivated

DATABYTE4 = always zero

**Transmits the module type:**

SID10-SID9 = 11 (lowest priority)  
SID8...SID1 = Module address  
RTR = 0  
DLC3...DLC0 = 7 databytes to send  
DATABYTE1 = COMMAND\_MODULE\_TYPE (H'FF')  
DATABYTE2 = VMBGP1 type (H'1E')  
DATABYTE3 = High byte of serial number  
DATABYTE4 = Low byte of serial number  
DATABYTE5 = Memorymap version  
DATABYTE6 = Build year  
DATABYTE7 = Build week

**Transmits the module subtype:**

SID10-SID9 = 11 (lowest priority)  
SID8...SID1 = Module address  
RTR = 0  
DLC3...DLC0 = 8 databytes to send  
DATABYTE1 = COMMAND\_SUBTYPE (H'B0')  
DATABYTE2 = VMBGP1 type (H'1E')  
DATABYTE3 = High byte of serial number  
DATABYTE4 = Low byte of serial number  
DATABYTE5 = Subaddress1 (H'FF' subaddress disabled)  
DATABYTE6 = Subaddress2 (H'FF' subaddress disabled)  
DATABYTE7 = Subaddress3 (H'FF' subaddress disabled)  
DATABYTE8 = Subaddress4 (H'FF' subaddress disabled)

**Transmit: Bus error counter status**

SID10-SID9 = 11 (lowest priority)  
SID8...SID1 = Module address  
RTR = 0  
DLC3...DLC0 = 4 databytes to send  
DATABYTE1 = COMMAND\_BUSERRO\_COUNTER\_STATUS (H'DA')  
DATABYTE2 = Transmit error counter  
DATABYTE3 = Receive error counter  
DATABYTE4 = Bus off counter

***Transmits the memory data:***

SID10-SID9 = 11 (lowest priority)  
SID8...SID1 = Module address  
RTR = 0  
DLC3...DLC0 = 4 databytes to send  
DATABYTE1 = COMMAND\_MEMORY\_DATA (H'FE')  
DATABYTE2 = High memory address  
DATABYTE3 = LOW memory address  
DATABYTE4 = memory data

Remark: address range: H'0000' to H'03FF'

***Transmits memory data block (4 bytes):***

SID10-SID9 = 11 (lowest priority)  
SID8...SID1 = Module address  
RTR = 0  
DLC3...DLC0 = 7 databytes to send  
DATABYTE1 = COMMAND\_MEMORY\_DATA\_BLOCK (H'CC')  
DATABYTE2 = High start address of memory block  
DATABYTE3 = LOW start address of memory block  
DATABYTE4 = memory data1  
DATABYTE5 = memory data2  
DATABYTE6 = memory data3  
DATABYTE7 = memory data4

Remark: address range: H'0000' to H'03FC'

***Transmits the first part of channel name:***

SID10-SID9 = 11 (lowest priority)  
SID8...SID1 = Module address  
RTR = 0  
DLC3...DLC0 = 8 databytes to send  
DATABYTE1 = COMMAND\_CHANNEL\_NAME\_PART1 (H'F0')  
DATABYTE2 = channel number 1...9 (channel 9 = temperature sensor name)  
DATABYTE3 = Character 1 of the channel name  
DATABYTE4 = Character 2 of the channel name  
DATABYTE5 = Character 3 of the channel name  
DATABYTE6 = Character 4 of the channel name  
DATABYTE7 = Character 5 of the channel name  
DATABYTE8 = Character 6 of the channel name

***Transmits the second part of the channel name:***

SID10-SID9 = 11 (lowest priority)  
SID8...SID1 = Module address  
RTR = 0  
DLC3...DLC0 = 8 databytes to send  
DATABYTE1 = COMMAND\_CHANNEL\_NAME\_PART2 (H'F1')  
DATABYTE2 = Channel number 1...9 (channel 9 = temperature sensor name)  
DATABYTE3 = Character 7 of the channel name  
DATABYTE4 = Character 8 of the channel name  
DATABYTE5 = Character 9 of the channel name  
DATABYTE6 = Character 10 of the channel name  
DATABYTE7 = Character 11 of the channel name  
DATABYTE8 = Character 12 of the channel name

**Transmits the third part of the channel name:**

- SID10-SID9 = 11 (lowest priority)
- SID8...SID1 = Module address
- RTR = 0
- DLC3...DLC0 = 6 databytes to send
- DATABYTE1 = COMMAND\_CHANNEL\_NAME\_PART3 (H'F2')
- DATABYTE2 = channel number 1...9 (channel 9 = temperature sensor name)
- DATABYTE3 = Character 13 of the channel name
- DATABYTE4 = Character 14 of the channel name
- DATABYTE5 = Character 15 of the channel name
- DATABYTE6 = Character 16 of the channel name

Remarks:

Unused characters contain H'FF'.

**Transmits the module status:**

- SID10-SID9 = 11 (lowest priority)
- SID8...SID1 = Module address
- RTR = 0
- DLC3...DLC0 = 7 databytes to send
- DATABYTE1 = COMMAND\_MODULE\_STATUS (H'ED')
- DATABYTE2 = channel 1 to 8 status (1 = pressed / 0 = released)
- DATABYTE3 = enabled/disable channel status (1 = enabled / 0 = disabled)
- DATABYTE4 = normal/inverted channel status (1 = normal / 0 = inverted)
- DATABYTE5 = locked channel status (0 = unlocked / 1 = locked)
- DATABYTE6 = disabled channel program status (0 = program enabled / 1 = program disabled)
- DATABYTE7 = alarm & program selection

Contents	Selected program
B'xxxxxx00'	None
B'xxxxxx01'	Program group 1 (Summer)
B'xxxxxx10'	Program group 2 (Winter)
B'xxxxxx11'	Program group 3 (Holiday)
B'xxxx0xx'	Clock alarm 1 off
B'xxxx1xx'	Clock alarm 1 on
B'xxx0xxx'	Local clock alarm 1
B'xxx1xxx'	Global clock alarm 1
B'xx0xxxx'	Clock alarm 2 off
B'xx1xxxx'	Clock alarm 2 on
B'xx0xxxxx'	Local clock alarm 2
B'xx1xxxxx'	Global clock alarm 2
B'x0xxxxxx'	Sunrise disabled
B'x1xxxxxx'	Sunrise enabled
B'0xxxxxxx'	Sunset disabled
B'1xxxxxxx'	Sunset enabled

**Transmit the sensor status:**

- SID10-SID9 = 11 (lowest priority)
- SID8...SID1 = Module address
- RTR = 0
- DLC3...DLC0 = 8 databytes to send
- DATABYTE1 = COMMAND\_TEMP\_SENSOR\_STATUS (H'EA')
- DATABYTE2 = Operating mode

Contents	Operating mode
xxxxxxx1	Mode push button locked
xxxxxxx0	Mode push button unlocked
Xxxxx11x	Disable mode
xxxxx01x	Manual mode
xxxxx10x	Sleep timer mode
xxxxx00x	Run mode
xxxx1xxx	Auto send sensor temperature enabled
xxxx0xxx	Auto send sensor temperature disabled
x100xxxx	Comfort mode
x010xxxx	Day mode

x001xxxx	Night mode
x000xxxx	Safe temp mode (anti frost)
1xxxxxxx	Cooler mode
0xxxxxxx	Heater mode

DATABYTE3 = Program step mode

Contents	Program step mode
xxxxx0xx	No sensor program group 1
xxxxx1xx	Sensor program group 1 available
xxxx0xxx	No sensor program group 2
xxxx1xxx	Sensor program group 2 available
0xxxxxxx	No sensor program group 3
1xxxxxxx	Sensor program group 3 available
x100xxxx	Comfort program step received
x010xxxx	Day program step received
x001xxxx	Night program step received
X000xxxx	Safe temperature program step received
xxxxxx1x	Enable unjamming heater valve
xxxxxx0x	Disable unjamming heater valve
xxxxxxx1	Enable unjamming pump
xxxxxxx0	Disable unjamming pump

DATABYTE4 = Output status (1 = activated)

Contents	Output channel
xxxxxxx0	Heater off
xxxxxxx1	Heater on
xxxxxx0x	Boost heater/cooler off
xxxxxx1x	Boost heater/cooler on
xxxxx0xx	Pump off
xxxxx1xx	Pump on
xxxx0xxx	Cooler off
xxxx1xxx	Cooler on
xxx0xxxx	Temperature alarm 1 off
xxx1xxxx	Temperature alarm 1 on
xx0xxxxx	Temperature alarm 2 off
xx1xxxxx	Temperature alarm 2 on
x0xxxxxx	Temperature alarm 3 off
x1xxxxxx	Temperature alarm 3 on
0xxxxxxx	Temperature alarm 4 off
1xxxxxxx	Temperature alarm 4 on

DATABYTE5 = Current sensor temperature into two's complement format (resolution 0.5°)

Contents	Current sensor temperature
01111111	63.5°C
00000001	0.5°C
00000000	0°C
11111111	-0.5°C
10010010	-55°C

DATABYTE6 = Current temperature set (resolution 0.5°)

Contents	Current temperature set
01101100	54°C
00101000	20°C
00000010	1°C
00000001	0.5°C
00000000	0°C
11111111	-0.5°C
11000000	-32°C

DATABYTE7 = High byte of the sleep timer

DATABYTE8 = Low byte of the sleep timer into minutes



Remark:

[DATABYTE7][DATABYTE8] contains a 16-bit sleep timer into minutes (1 to 65.279min).

If the sleep timer contains H'0000', the sleep timer is deactivated.

If the sleep timer contains a value between H'0001' and H'FEFF' (1 to 65.279min), the sleep timer is running for that time.

If the sleep timer contains H'FFFF', the sensor is in manual mode.

**Transmit the sensor temperature:**

SID10-SID9 = 11 (lowest priority)

SID8...SID1 = Module address

RTR = 0

DLC3...DLC0 = 7 databytes to send

DATABYTE1 = COMMAND\_SENSOR\_TEMPERATURE (H'E6')

DATABYTE2 = High byte current sensor temperature

DATABYTE3 = Low byte current sensor temperature into two's complement format (resolution 0.0625°)

DATABYTE4 = High byte minimum sensor temperature

DATABYTE5 = Low byte minimum sensor temperature into two's complement format (resolution 0.0625°)

DATABYTE6 = High byte maximum sensor temperature

DATABYTE7 = Low byte maximum sensor temperature into two's complement format (resolution 0.0625°)

High byte	Low byte	Current sensor temperature
01111111	11100000	63.5°C
00000001	00000000	0.5°C
00000000	10000000	0.25°C
00000000	01000000	0.125°C
00000000	00100000	0.0625°C
00000000	00000000	0°C
11111111	11111111	-0.0625°C
11111111	11011111	-0.125°C
11111111	10011111	-0.25°C
11111110	00011111	-0.5°C
10010010	00011111	-55°C

Remark:

The 5 least significant bits of the low byte are always zero.

The low order bytes are not sending with the data length of 4 bytes (resolution 0.5°C)

**Transmit time statistics**

SID10-SID9 = 11 (lowest priority)

SID8...SID1 = Module address

RTR = 0

DLC3...DLC0 = 8 databytes to send

DATABYTE1 = COMMAND\_TIME\_STATISTICS (H'C8')

DATABYTE2 = statistics mode index

Contents	Time statistics
10000001	Heating antifreeze mode time statistics
10000010	Heating night mode time statistics
10000100	Heating day mode time statistics
10001000	Heating comfort mode time statistics
10010000	Heating global time statistics
01000001	Cooling standby mode time statistics
01000010	Cooling night mode time statistics
01000100	Cooling day mode time statistics
01001000	Cooling comfort mode time statistics
01010000	Cooling global time statistics

DATABYTE3 = 'ON' time (hours bcd digits 4 & 3)

DATABYTE4 = 'ON' time (hours bcd digits 2 & 1)

DATABYTE5 = 'ON' time (minutes bcd digits 2 & 1)

DATABYTE6 = Mode time (hours bcd digits 4 & 3)

DATABYTE7 = Mode time (hours bcd digits 2 & 1)

DATABYTE8 = Mode time (minutes bcd digits 2 & 1)

Remark:

The time is bcd formatted.

Databytes 3, 4 & 5 gives the total 'ON' time of the heater or cooler in the corresponding mode.

Databytes 6, 7 & 8 gives the total time of selected mode.

**Transmit the first part of the sensor settings:**

SID10-SID9 = 11 (lowest priority)

SID8...SID1 = Module address

RTR = 0

DLC3...DLC0 = 8 databytes to send

DATABYTE1 = COMMAND\_TEMP\_SENSOR\_SETTINGS\_PART1 (H'E8')

DATABYTE2 = Current temperature set (resolution 0.5°)

DATABYTE3 = Comfort temperature set for heating mode (resolution 0.5°)

DATABYTE4 = Day temperature set for heating mode (resolution 0.5°)

DATABYTE5 = Night temperature set for heating mode (resolution 0.5°)

DATABYTE6 = Anti frost temperature set for heating mode (resolution 0.5°)

DATABYTE7 = Boost temperature difference set (resolution 0.5°)

DATABYTE8 = Hysteresis temperature set

Contents	Hysteresis
xxx11111	15.5°C
Xxx00001	0.5°C
Xxx00000	0°C

**Transmit the second part of the sensor settings:**

SID10-SID9 = 11 (lowest priority)

SID8...SID1 = Module address

RTR = 0

DLC3...DLC0 = 8 databytes to send

DATABYTE1 = COMMAND\_TEMP\_SENSOR\_SETTINGS\_PART2 (H'E9')

DATABYTE2 = Comfort temperature set for cooling mode (resolution 0.5°)

DATABYTE3 = Day temperature set for cooling mode (resolution 0.5°)

DATABYTE4 = Night temperature set for cooling mode (resolution 0.5°)

DATABYTE5 = Safe temperature set for cooling mode (resolution 0.5°)

DATABYTE6 = High byte of the default sleep timer

DATABYTE7 = Low byte of the default sleep timer into minutes (1 to 65.279min)

DATABYTE8 = Default auto send temperature time interval into seconds

(Valid range: 10...255s)

(5...9 = auto send on temperature change with min interval 5...9s)

(<4 = auto send disabled)

**Transmit the third part of the sensor settings:**

SID10-SID9 = 11 (lowest priority)

SID8...SID1 = Module address

RTR = 0

DLC3...DLC0 = 8 databytes to send

DATABYTE1 = COMMAND\_TEMP\_SENSOR\_SETTINGS\_PART3 (H'C6')

DATABYTE2 = Temperature alarm 1 setting (resolution 0.5°)

DATABYTE3 = Temperature alarm 4 setting (resolution 0.5°)

DATABYTE4 = Lower temperature range cool mode (resolution 0.5°)

DATABYTE5 = Upper temperature range heat mode (resolution 0.5°)

DATABYTE6 = Calibration offset factor (resolution 0.5°)

Contents	Calibration factor
00001111	Calibration factor +7.5°C
00000001	Calibration factor +0.5°C
00000000	Calibration factor +0°C
11111111	Calibration factor -0.5°C
11110000	Calibration factor -8°C

DATABYTE7 = Zone number

DATABYTE8 = Calibration gain factor

**Transmit the fourth part of the sensor settings:**

SID10-SID9 = 11 (lowest priority)  
SID8...SID1 = Module address  
RTR = 0  
DLC3...DLC0 = 2 databytes to send  
DATABYTE1 = COMMAND\_TEMP\_SENSOR\_SETTINGS\_PART4 (H'B9')  
DATABYTE2 = Minimum switching time (0...255s)  
DATABYTE3 = Pump delayed on time (0...255s)  
DATABYTE4 = Pump delayed off time (0...255s)  
DATABYTE5 = Temperature alarm 2 setting (resolution 0.5°)  
DATABYTE6 = Temperature alarm 3 setting (resolution 0.5°)  
DATABYTE7 = Lower temperature range heat mode (resolution 0.5°)  
DATABYTE8 = Upper temperature range cool mode (resolution 0.5°)

**Transmit: Clears LEDs on a linked push button module:**

SID10-SID9 = 11 (lowest priority)  
SID8...SID1 = Address of the linked push button module for clearing LEDs  
RTR = 0  
DLC3...DLC0 = 2 databytes to send  
DATABYTE1 = COMMAND\_CLEAR\_LED (H'F5')  
DATABYTE2 = LED bit numbers (1 = clear LED)

**Transmit: Sets LEDs on a linked push button module:**

SID10-SID9 = 11 (lowest priority)  
SID8...SID1 = Address of the linked push button module for setting LEDs on  
RTR = 0  
DLC3...DLC0 = 2 databytes to send  
DATABYTE1 = COMMAND\_SET\_LED (H'F6')  
DATABYTE2 = LED bit numbers (1 = set LED)

**Transmit: Blinks LEDs slowly on a linked push button module:**

SID10-SID9 = 11 (lowest priority)  
SID8...SID1 = Address of the linked push button module for slowly blinking LEDs  
RTR = 0  
DLC3...DLC0 = 2 databytes to send  
DATABYTE1 = COMMAND\_SLOW\_BLINKING\_LED (H'F7')  
DATABYTE2 = LED bit numbers (1 = slow blink LED)

**Transmit: Blinks LEDs fast on a linked push button module:**

SID10-SID9 = 11 (lowest priority)  
SID8...SID1 = Address of the linked push button module for fast blinking LEDs  
RTR = 0  
DLC3...DLC0 = 2 databytes to send  
DATABYTE1 = COMMAND\_FAST\_BLINKING\_LED (H'F8')  
DATABYTE2 = LED bit numbers (1 = fast blink LED)

**Transmits program step info:**

SID10-SID9 = 11 (lowest priority)  
SID8...SID1 = Module address  
RTR = 0  
DLC3...DLC0 = 8 databytes to send  
DATABYTE1 = COMMAND\_PROGRAM\_STEP\_INFO (H'C1')  
DATABYTE2 = Program step number (1...85 / 255 step not found)  
DATABYTE3 = Program reference

<i>Contents</i>	<i>Description</i>
000xxxxx	Disable program step
001xxxxx	Absolute time
010xxxxx	Wake up time 1 + relative time
011xxxxx	Go to bed time 1 + relative time
100xxxxx	Wake up time 2 + relative time
101xxxxx	Go to bed time 2 + relative time
110xxxxx	Sunrise + relative time
111xxxxx	Sunset + relative time
xxx01111	Rel. time = 3h45min

...	
xxx00001	Rel. time = 15min
xxx00000	Rel. time = 0
xxx11111	Rel. time = -15min
...	
xxx10000	Rel. time = -4h

DATABYTE4 = Program step month & four least significant bits of day

<i>Contents</i>	<i>Description</i>
xxxx0000	Weekly program
xxxx0001	January
xxxx0010	February
xxxx0011	March
xxxx0100	April
xxxx0101	May
xxxx0110	June
xxxx0111	July
xxxx1000	August
xxxx1001	September
xxxx1010	October
xxxx1011	November
xxxx1100	December
xxxx1101	Monthly program
xxxx1110	Monthly program
xxxx1111	Monthly program

<i>Contents byte6</i>	<i>Contents byte4</i>	<i>Description</i>
00xxxxxx	0000xxxx	Never
00xxxxxx	0001xxxx	Day 1 of the month
00xxxxxx	0010xxxx	Day 2 of the month
...	...	...
01xxxxxx	1111xxxx	Day 31 of the month
10xxxxxx	0000xxxx	Never
10xxxxxx	0001xxxx	Every Monday
10xxxxxx	0010xxxx	Every Tuesday
...	...	...
10xxxxxx	0111xxxx	Every Sunday
10xxxxxx	1000xxxx	Every weekend (sa & su)
10xxxxxx	1001xxxx	Every working day (mo...fr)
10xxxxxx	1010xxxx	Every day except Sunday
10xxxxxx	1011xxxx	Every day
10xxxxxx	1100xxxx	Never
...	...	...
11xxxxxx	1111xxxx	Never

DATABYTE5 = Program step hour & group number

<i>Contents</i>	<i>Description</i>
xxx00000	0h
xxx00001	1h
...	...
xxx10111	23h
xx1xxxxx	Program group 1 (Summer program)
x1xxxxxx	Program group 2 (Winter program)
1xxxxxxx	Program group 3 (Holiday program)

DATABYTE6 = Program step minute & every flag & msb of day

<i>Contents</i>	<i>Description</i>
xx000000	0min
xx000001	1min
...	...
xx111011	59min

<i>Contents byte6</i>	<i>Contents byte4</i>	<i>Description</i>
00xxxxxx	0000xxxx	Never
00xxxxxx	0001xxxx	Day 1 of the month
00xxxxxx	0010xxxx	Day 2 of the month
...	...	...
01xxxxxx	1111xxxx	Day 31 of the month
10xxxxxx	0000xxxx	Never
10xxxxxx	0001xxxx	Every Monday
10xxxxxx	0010xxxx	Every Tuesday
...	...	...
10xxxxxx	0111xxxx	Every Sunday
10xxxxxx	1000xxxx	Every weekend (sa & su)
10xxxxxx	1001xxxx	Every working day (mo...fr)
10xxxxxx	1010xxxx	Every day except Sunday
10xxxxxx	1011xxxx	Every day
10xxxxxx	1100xxxx	Never
...	...	...
11xxxxxx	1111xxxx	Never

DATABYTE7 = Program step action

<b>Contents</b>	<b>Action</b>
0	0s25 Pulse
1	1s Pulse
2	2s Pulse
...	...
119	1min59s Pulse
120	2min Pulse
121	2min15s Pulse
...	...
131	4min45s Pulse
132	5min Pulse
133	5min30s Pulse
...	...
181	29min30s Pulse
182	30min Pulse
183	31min Pulse
...	...
211	59min Pulse
212	1h Pulse
213	1h15min Pulse
...	...
227	4h45min Pulse
228	5h Pulse
229	5h30min Pulse
...	...
237	9h30min Pulse
238	10h Pulse
239	11h Pulse
...	...
246	18h Pulse
247	Press
248	Long Press
249	Release
250	Lock
251	Unlock
252	Sensor: Safe mode
253	Sensor: Night mode
254	Sensor: Day mode
255	Sensor: Comfort mode

DATABYTE8 = Channel

Contents	Channel
1	Channel 1 or temperature sensor
2	Channel 2
...	...
7	Channel 7
8	Channel 8

***'Linked push button status' received:***

SID10-SID9 = 00 (highest priority)  
SID8...SID1 = Address of the linked push button module  
RTR = 0  
DLC3...DLC0 = 4 databytes received  
DATABYTE1 = COMMAND\_PUSH\_BUTTON\_STATUS (H'00')  
DATABYTE2 = Linked push buttons just pressed (1 = just pressed)  
DATABYTE3 = Linked push buttons just released (1 = just released)  
DATABYTE4 = linked push buttons long pressed (1 = longer than 0.85s pressed)

***'Real time clock status request' command received:***

SID10-SID9 = 11 (lowest priority)  
SID8...SID1 = H'00'  
RTR = 0  
DLC3...DLC0 = 1 databyte to send  
DATABYTE1 = COMMAND\_REALTIME\_CLOCK\_STATUS\_REQUEST (H'D7')

Remark: The real time clock status will only be send if master clock is on

***'Set real time clock' command received:***

SID10-SID9 = 11 (lowest priority)  
SID8...SID1 = H'00'  
RTR = 0  
DLC3...DLC0 = 4 databytes to send  
DATABYTE1 = COMMAND\_SET\_REALTIME\_CLOCK (H'D8')  
DATABYTE2 = Day of week

<i>Contents day of week'</i>	<i>Description</i>
H'00'	Monday
H'01'	Tuesday
H'02'	Wednesday
H'03'	Thursday
H'04'	Friday
H'05'	Saturday
H'06'	Sunday

DATABYTE3 = Hours (0...23)  
DATABYTE4 = Minutes (0...59)

***'Set date' command received:***

SID10-SID9 = 11 (lowest priority)  
SID8...SID1 = H'00'  
RTR = 0  
DLC3...DLC0 = 5 databytes to send  
DATABYTE1 = COMMAND\_SET\_REALTIME\_DATE (H'B7')  
DATABYTE2 = Day (1...31)  
DATABYTE3 = Month (1...12)  
DATABYTE4 = High byte of Year  
DATABYTE5 = Low byte of Year

***'Set daylight savings' command received:***

SID10-SID9 = 11 (lowest priority)  
SID8...SID1 = H'00'  
RTR = 0  
DLC3...DLC0 = 2 databytes to send  
DATABYTE1 = COMMAND\_SET\_DAYLIGHT\_SAVING (H'AF')  
DATABYTE2 = 0 =disabled / 1 = enabled

***‘Enable/disable global sunrise/sunset related actions’ command received:***

SID10-SID9 = 11 (lowest priority)  
SID8...SID1 = H'00'  
RTR = 0  
DLC3...DLC0 = 3 databytes to send  
DATABYTE1 = COMMAND\_ENA\_DIS\_SUNRISE\_SUNSET (H'AE')  
DATABYTE2 = Channel (FF)  
DATABYTE3 = enable/disable flags

<b><i>Contents</i></b>	<b><i>Description</i></b>
B'xxxxxxx0'	Disable sunrise related actions
B'xxxxxxx1'	Enable sunrise related actions
B'xxxxxx0x'	Disable sunset related actions
B'xxxxxx1x'	Enable sunset related actions

***‘Enable/disable local sunrise/sunset related actions’ command received:***

SID10-SID9 = 11 (lowest priority)  
SID8...SID1 = Module address  
RTR = 0  
DLC3...DLC0 = 3 databytes to send  
DATABYTE1 = COMMAND\_ENA\_DIS\_SUNRISE\_SUNSET (H'AE')  
DATABYTE2 = Channel (FF)  
DATABYTE3 = enable/disable flags

<b><i>Contents</i></b>	<b><i>Description</i></b>
B'xxxxxxx0'	Disable sunrise related actions
B'xxxxxxx1'	Enable sunrise related actions
B'xxxxxx0x'	Disable sunset related actions
B'xxxxxx1x'	Enable sunset related actions

***‘Set global clock alarm’ command received:***

SID10-SID9 = 11 (lowest priority)  
SID8...SID1 = H'00'  
RTR = 0  
DLC3...DLC0 = 7 databytes to send  
DATABYTE1 = COMMAND\_SET\_ALARM\_CLOCK (H'C3')  
DATABYTE2 = Alarm number (1 or 2)  
DATABYTE3 = Wake up hour (0...23)  
DATABYTE4 = Wake up minute (0...59)  
DATABYTE5 = Go to bed hour (0...23)  
DATABYTE6 = Go to bed minute (0...59)  
DATABYTE7 = Clock alarm enable flag (0 = disabled / 1 = enabled)

***‘Set local clock alarm’ command received:***

SID10-SID9 = 11 (lowest priority)  
SID8...SID1 = Module address  
RTR = 0  
DLC3...DLC0 = 7 databytes to send  
DATABYTE1 = COMMAND\_SET\_ALARM\_CLOCK (H'C3')  
DATABYTE2 = Alarm number (1 or 2)  
DATABYTE3 = Wake up hour (0...23)  
DATABYTE4 = Wake up minute (0...59)  
DATABYTE5 = Go to bed hour (0...23)  
DATABYTE6 = Go to bed minute (0...59)  
DATABYTE7 = Clock alarm enable flag (0 = disabled / 1 = enabled)

***‘Module type request’ command received:***

SID10-SID9 = 11 (lowest priority)  
SID8...SID1 = Module address  
RTR = 1  
DLC3...DLC0 = 0 databytes received



***‘Module status request’ command received:***

SID10-SID9 = 11 (lowest priority)  
SID8...SID1 = Module address  
RTR = 0  
DLC3...DLC0 = 2 databytes received  
DATATYPE1 = COMMAND\_MODULE\_STATUS\_REQUEST (H'FA')  
DATATYPE2 = don't care

***‘Channel name request’ command received:***

SID10-SID9 = 11 (lowest priority)  
SID8...SID1 = Module address  
RTR = 0  
DLC3...DLC0 = 2 databytes received  
DATATYPE1 = COMMAND\_CHANNEL\_NAME\_REQUEST (H'EF')  
DATATYPE2 = channel number 1...9 (9 for temperature sensor name)

Remark: channel = H'FF' for all 8 channel names & temperature sensor name

***‘Clear channel LED’ command received:***

SID10-SID9 = 11 (lowest priority)  
SID8...SID1 = Module address  
RTR = 0  
DLC3...DLC0 = 2 databytes received  
DATATYPE1 = COMMAND\_CLEAR\_LED (H'F5')  
DATATYPE2 = LEDs to clear (a one clears the corresponding LED of channel 1 to 8)

***‘Set channel LED’ command received:***

SID10-SID9 = 11 (lowest priority)  
SID8...SID1 = Module address  
RTR = 0  
DLC3...DLC0 = 2 databytes received  
DATATYPE1 = COMMAND\_SET\_LED (H'F6')  
DATATYPE2 = LEDs to set (a one sets the corresponding LED of channel 1 to 8)

***‘Slow blink channel LED’ command received:***

SID10-SID9 = 11 (lowest priority)  
SID8...SID1 = Module address  
RTR = 0  
DLC3...DLC0 = 2 databytes received  
DATATYPE1 = COMMAND\_SLOW\_BLINK\_LED (H'F7')  
DATATYPE2 = LEDs to blink slow (a one blinks slow the corresponding LED of channel 1 to 8)

***‘Fast blink channel LED’ command received:***

SID10-SID9 = 11 (lowest priority)  
SID8...SID1 = Module address  
RTR = 0  
DLC3...DLC0 = 2 databytes received  
DATATYPE1 = COMMAND\_FAST\_BLINK\_LED (H'F8')  
DATATYPE2 = LEDs to blink fast (a one blinks fast the corresponding LED of channel 1 to 8)

***‘Very fast blink channel LED’ command received:***

SID10-SID9 = 11 (lowest priority)  
SID8...SID1 = Module address  
RTR = 0  
DLC3...DLC0 = 2 databytes received  
DATATYPE1 = COMMAND\_VERY\_FAST\_BLINK\_LED (H'F9')  
DATATYPE2 = LEDs to blink very fast (a one blinks very fast the corresponding LED of channel 1 to 8)

***'Update channel LEDs' command received:***

SID10-SID9 = 11 (lowest priority)  
SID8...SID1 = Module address  
RTR = 0  
DLC3...DLC0 = 4 databytes received  
DATABYTE1 = COMMAND\_UPDATE\_LED\_STATUS (H'F4')  
DATABYTE2 = LEDs to set (a one sets the corresponding LED of channel 1 to 8)  
DATABYTE3 = LEDs to blink slow (a one blinks slow the corresponding LED of channel 1 to 8)  
DATABYTE4 = LEDs to blink fast (a one blinks very fast the corresponding LED of channel 1 to 8)

Remark:

The 'LEDs to set' status overrides the blinking modes.  
Very fast blinking if slow & fast blinking are set.

***'Read data from memory' command received:***

SID10-SID9 = 11 (lowest priority)  
SID8...SID1 = Module address  
RTR = 0  
DLC3...DLC0 = 3 databytes received  
DATABYTE1 = COMMAND\_READ\_DATA\_FROM\_MEMORY (H'FD')  
DATABYTE2 = High memory address  
DATABYTE3 = LOW memory address

Remark: address range: H'0000' to H'03FF'

***'Read data block from memory' command received:***

SID10-SID9 = 11 (lowest priority)  
SID8...SID1 = Module address  
RTR = 0  
DLC3...DLC0 = 3 databytes received  
DATABYTE1 = COMMAND\_READ\_MEMORY\_BLOCK (H'C9')  
DATABYTE2 = High memory address  
DATABYTE3 = LOW memory address

Remark: address range: H'0000' to H'03FC'

***'Memory dump request' command received:***

SID10-SID9 = 11 (lowest priority)  
SID8...SID1 = Module address  
RTR = 0  
DLC3...DLC0 = 1 databytes received  
DATABYTE1 = COMMAND\_MEMORY\_DUMP\_REQUEST (H'CB')

***'Write data to memory' command received:***

SID10-SID9 = 11 (lowest priority)  
SID8...SID1 = Module address  
RTR = 0  
DLC3...DLC0 = 4 databytes received  
DATABYTE1 = COMMAND\_WRITE\_DATA\_TO\_MEMORY (H'FC')  
DATABYTE2 = High memory address  
DATABYTE3 = LOW memory address  
DATABYTE4 = memory data to write

Remark:

Wait at least 10ms for sending a next command on the velbus.  
Address range: H'0000' to H'03FF'  
Terminate always with a write command at the last memory location.

***‘Write memory block’ command received:***

SID10-SID9 = 11 (lowest priority)  
SID8...SID1 = Module address  
RTR = 0  
DLC3...DLC0 = 7 databytes received  
DATABYTE1 = COMMAND\_WRITE\_MEMORY\_BLOCK (H‘CA’)  
DATABYTE2 = High memory address  
DATABYTE3 = LOW memory address  
DATABYTE4 = memory databyte1 to write  
DATABYTE5 = memory databyte2 to write  
DATABYTE6 = memory databyte3 to write  
DATABYTE7 = memory databyte4 to write

**Remark:**

Wait for ‘memory data block’ feedback before sending a next command on the velbus.  
Terminate always with a write command at the last memory location.  
Address range: H‘0000’ to H‘03FC’

***‘Bus error counter status request’ command received:***

SID10-SID9 = 11 (lowest priority)  
SID8...SID1 = Module address  
RTR = 0  
DLC3...DLC0 = 1 databytes to send  
DATABYTE1 = COMMAND\_BUS\_ERROR\_COUNTER\_STATUS\_REQUEST (H‘D9’)

***‘Unlock channel’ command received:***

SID10-SID9 = 00 (highest priority)  
SID8...SID1 = Module address  
RTR = 0  
DLC3...DLC0 = 2 databytes received  
DATABYTE1 = COMMAND\_CANCEL\_FORCED\_OFF (H‘13’)  
DATABYTE2 = Channel number (1...9 (9 for enable temperature sensor))

Remark: channel number = H‘FF’ for all 8 channels

***‘Lock channel’ command received:***

SID10-SID9 = 00 (highest priority)  
SID8...SID1 = Module address  
RTR = 0  
DLC3...DLC0 = 5 databytes received  
DATABYTE1 = COMMAND\_FORCED\_OFF (H‘12’)  
DATABYTE2 = Channel number (1...9 (9 for disable temperature sensor))  
DATABYTE3 = high byte of delay time  
DATABYTE4 = mid byte of delay time  
DATABYTE5 = low byte of delay time

**Remark:**

Channel number = H‘FF’ for all 8 channels  
[DATABYTE3][DATABYTE4][DATABYTE5] contain a 24-bit time in seconds  
The command will be skipped when the time parameter contains zero.  
When the time parameter contains H‘FFFFFF’ then the channel will be permanently locked.

***‘Enable Channel Program’ command received:***

SID10-SID9 = 11 (lowest priority)  
SID8...SID1 = Module address  
RTR = 0  
DLC3...DLC0 = 2 databytes received  
DATABYTE1 = COMMAND\_ENABLE\_PROGRAM (H‘B2’)  
DATABYTE2 = Channel number (1...8)

Remark: channel number = H‘FF’ for all 8 channels

***‘Disable Channel Program’ command received:***

SID10-SID9 = 11 (lowest priority)  
SID8...SID1 = Module address  
RTR = 0  
DLC3...DLC0 = 5 databytes received  
DATABYTE1 = COMMAND\_DISABLE\_PROGRAM (H‘B1’)  
DATABYTE2 = Channel number (1...8)  
DATABYTE3 = high byte of delay time  
DATABYTE4 = mid byte of delay time  
DATABYTE5 = low byte of delay time

**Remark:**

Channel number = H‘FF’ for all 8 channels  
[DATABYTE3][DATABYTE4][DATABYTE5] contain a 24-bit time in seconds  
The command will be skipped when the time parameter contains zero.  
When the time parameter contains H‘FFFFFF’ then the channel program will be permanently disabled.

***‘Select Program’ command received:***

SID10-SID9 = 11 (lowest priority)  
SID8...SID1 = Module address  
RTR = 0  
DLC3...DLC0 = 2 databytes received  
DATABYTE1 = COMMAND\_SELECT\_PROGRAM (H‘B3’)  
DATABYTE2 = Program mode

<i>Contents</i>	<i>Selected programl</i>
0	None
1	Program group 1 (Summer)
2	Program group 2 (Winter)
3	Program group 3 (Holiday)

***‘Sensor temperature request’ command received:***

SID10-SID9 = 11 (lowest priority)  
SID8...SID1 = Module address  
RTR = 0  
DLC3...DLC0 = 2 databytes to send  
DATABYTE1 = COMMAND\_SENSOR\_TEMP\_REQUEST (H‘E5’)  
DATABYTE2 = Autosend time interval into seconds  
(valid range: 10...255s)  
(5...9 = auto send on temperature change)  
(1...4 = auto send disabled)  
(0 = no change on auto send interval)

***‘Sensor settings request’ command received:***

SID10-SID9 = 11 (lowest priority)  
SID8...SID1 = Module address  
RTR = 0  
DLC3...DLC0 = 2 databytes to send  
DATABYTE1 = COMMAND\_TEMP\_SENSOR\_SETTINGS\_REQUEST (H‘E7’)  
DATABYTE2 = don’t care

***‘Set heating mode’ command received:***

SID10-SID9 = 11 (lowest priority)  
SID8...SID1 = Module address  
RTR = 0  
DLC3...DLC0 = 2 databytes received  
DATABYTE1 = COMMAND\_SET\_HEATING\_MODE (H‘E0’)  
DATABYTE2 = don’t care

**‘Set cooling mode’ command received:**

SID10-SID9 = 11 (lowest priority)  
SID8...SID1 = Module address  
RTR = 0  
DLC3...DLC0 = 2 databytes received  
DATABYTE1 = COMMAND\_SET\_COOLING\_MODE (H'DF')  
DATABYTE2 = don't care

**‘Set sensor zone number’ command received:**

SID10-SID9 = 11 (lowest priority)  
SID8...SID1 = Module address  
RTR = 0  
DLC3...DLC0 = 2 databytes to send  
DATABYTE1 = COMMAND\_SET\_SENSOR\_ZONE\_NUMBER (H'C5')  
DATABYTE2 = Zone number (0= no zone / 1...7 = valid zone)

Remark: The module answers with his type

**‘Set default sleep time’ command received:**

SID10-SID9 = 11 (lowest priority)  
SID8...SID1 = Module address  
RTR = 0  
DLC3...DLC0 = 3 databytes received  
DATABYTE1 = COMMAND\_SET\_DEFAULT\_SLEEP\_TIME (H'E3')  
DATABYTE2 = High byte of the default sleep time  
DATABYTE3 = Low byte of the default sleep time into minutes  
(valid range H'0001' to H'FEFF' or 1min to 65.279min)

Remark: Wait at least 20ms for sending a next command on the velbus

**‘Set temperature’ command received:**

SID10-SID9 = 11 (lowest priority)  
SID8...SID1 = Module address  
RTR = 0  
DLC3...DLC0 = 3 databytes received  
DATABYTE1 = COMMAND\_SET\_TEMP (H'E4')  
DATABYTE2 = Pointer to temperature variable (0...20)

Contents	Temperature variable
0	Current temperature set
1	Comfort temperature set for heating
2	Day temperature set for heating
3	Night temperature set for heating
4	Safe temperature set for heating
5	Temperature difference for turbo output
6	Hysteresis (0°...15.5°C)
7	Comfort temperature set for cooling
8	Day temperature set for cooling
9	Night temperature set for cooling
10	Safe temperature set for cooling
11	Calibration offset factor (-8°...+7.5°C)
12	Reset minimum/maximum temperature
13	Reset time statistics
14	enable/disable anti-block valve/pump
15	Temperature alarm 1 set
16	Temperature alarm 4 set
17	Lower temperature range cool mode
18	Upper temperature range heat mode
19	Differential sensor address (H'FF' = no diff. sensor)
20	Target temperature set for the differential sensor
21	Minimum switching time
22	Pump delayed on time
23	Pump delayed off time
24	Temperature alarm 2 set
25	Temperature alarm 3 set

26	Lower temperature range heat mode
27	Upper temperature range cool mode
28	Calibration gain factor

DATABYTE3 = Temperature set (resolution 0.5°)

Contents	Temperature set
01111111	63.5°C
00101000	20°C
00000010	1°C
00000001	0.5°C
00000000	0°C
11111111	-0.5°C
10010010	-55°C

DATABYTE3 = Reset minimum/maximum temperature

Contents	Reset temperature
00000001	Reset minimum temperature
00000010	Reset maximum temperature

DATABYTE3 = Reset time statistics mode index

Contents	Reset time statistics
10000001	Reset heating antifreeze mode time statistics
10000010	Reset heating night mode time statistics
10000100	Reset heating day mode time statistics
10001000	Reset heating comfort mode time statistics
10010000	Reset heating global time statistics
01000001	Reset cooling standby mode time statistics
01000010	Reset cooling night mode time statistics
01000100	Reset cooling day mode time statistics
01001000	Reset cooling comfort mode time statistics
01010000	Reset cooling global time statistics

DATABYTE3 = Enable/disable unjamming heater valve & pump

Contents	Enable/disable unjamming valve and pump
00000000	Disable unjamming heater valve & pump
00000001	Disable unjamming heater valve & enable unjamming pump
00000010	Enable unjamming heater valve & disable unjamming pump
00000011	Enable unjamming heater valve & pump

DATABYTE3 = Minimum switching time:

Contents	Operating mode
00000000	No switching time protection
00000001	1 minute switching time protection
00000010	2 minute switching time protection
...	...
11111110	254 minute switching time protection
11111111	Default 1 minute switching time protection

Remark:

Valid hysteresis range = 0 ...15.5°C

Valid calibration factor range = -8 ...7.5°C

Wait at least 10ms for sending a next command on the velbus.

***‘Switch to comfort mode’ command received:***

SID10-SID9 = 11 (lowest priority)  
SID8...SID1 = Module address  
RTR = 0  
DLC3...DLC0 = 3 databytes received  
DATABYTE1 = COMMAND\_SWITCH\_TO\_COMFORT\_MODE (H'DB')  
DATABYTE2 = High byte of the sleep time  
DATABYTE3 = Low byte of the sleep time into minutes

**Remark:**

If the sleep time contains H'FF00', the command is a program step.

A sleep time between H'0001' and H'FEFF' (1 to 65.279min) starts the sleep timer for that time and program steps will not be executed during that time.

A sleep time of H'FFFF' puts the sensor into manual mode. Program steps will not be executed any more and local control is disabled.

A value of zero for the sleep time cancels the manual mode or sleep timer.

***‘Switch to day mode’ command received:***

SID10-SID9 = 11 (lowest priority)  
SID8...SID1 = Module address  
RTR = 0  
DLC3...DLC0 = 3 databytes received  
DATABYTE1 = COMMAND\_SWITCH\_TO\_DAY\_MODE (H'DC')  
DATABYTE2 = High byte of the sleep time  
DATABYTE3 = Low byte of the sleep time into minutes

**Remark:**

If the sleep time contains H'FF00', the command is a program step.

A sleep time between H'0001' and H'FEFF' (1 to 65.279min) starts the sleep timer for that time and program steps will not be executed during that time.

A sleep time of H'FFFF' puts the sensor into manual mode. Program steps will not be executed any more and local control is disabled.

A value of zero for the sleep time cancels the manual mode or sleep timer.

***‘Switch to night mode’ command received:***

SID10-SID9 = 11 (lowest priority)  
SID8...SID1 = Module address  
RTR = 0  
DLC3...DLC0 = 3 databytes received  
DATABYTE1 = COMMAND\_SWITCH\_TO\_NIGHT\_MODE (H'DD')  
DATABYTE2 = High byte of the sleep time  
DATABYTE3 = Low byte of the sleep time into minutes

**Remark:**

If the sleep time contains H'FF00', the command is a program step.

A sleep time between H'0001' and H'FEFF' (1 to 65.279min) starts the sleep timer for that time and program steps will not be executed during that time.

A sleep time of H'FFFF' puts the sensor into manual mode. Program steps will not be executed anymore and local control is disabled.

A value of zero for the sleep time cancels the manual mode or sleep timer.

**‘Switch to safe temperature mode’ command received:**

SID10-SID9 = 11 (lowest priority)  
SID8...SID1 = Module address  
RTR = 0  
DLC3...DLC0 = 3 databytes received  
DATABYTE1 = COMMAND\_SWITCH\_TO\_SAFE\_MODE (H'DE')  
DATABYTE7 = High byte of the sleep time  
DATABYTE8 = Low byte of the sleep time into minutes

**Remark:**

If the sleep time contains H'FF00', the command is a program step.

A sleep time between H'0001' and H'FEFF' (1 to 65.279min) starts the sleep timer for that time and program steps will not be executed during that time.

A sleep time of H'FFFF' puts the sensor into manual mode. Program steps will not be executed anymore and local control is disabled.

A value of zero for the sleep time cancels the manual mode or sleep timer.

**‘Time statistics request’ command received:**

SID10-SID9 = 11 (lowest priority)  
SID8...SID1 = Module address  
RTR = 0  
DLC3...DLC0 = 2 databytes to send  
DATABYTE1 = COMMAND\_TIME\_STATISTICS\_REQUEST (H'C7')  
DATABYTE2 = statistics mode index

Contents	Time statistics request
10000001	Heating antifreeze mode time statistics
10000010	Heating night mode time statistics
10000100	Heating day mode time statistics
10001000	Heating comfort mode time statistics
10010000	Heating global time statistics
01000001	Cooling standby mode time statistics
01000010	Cooling night mode time statistics
01000100	Cooling day mode time statistics
01001000	Cooling comfort mode time statistics
01010000	Cooling global time statistics

**‘Read program step’ command received:**

SID10-SID9 = 11 (lowest priority)  
SID8...SID1 = Module address  
RTR = 0  
DLC3...DLC0 = 5 databytes to send  
DATABYTE1 = COMMAND\_READ\_PROGRAM\_STEP (H'C0')  
DATABYTE2 = Start program step number (1...85)  
DATABYTE3 = Program group number (1...3)  
DATABYTE4 = Channel (1...8 for buttons or 128 for temperature channel)  
DATABYTE5 = Search direction (1 = search for next matched step / 0 = search for previous matched program step)

**‘Write program step’ command received:**

SID10-SID9 = 11 (lowest priority)  
SID8...SID1 = Module address  
RTR = 0  
DLC3...DLC0 = 8 databytes to send  
DATABYTE1 = COMMAND\_WRITE\_PROGRAM\_STEP (H'C2')  
DATABYTE2 = Program step number (1...85)  
DATABYTE3 = Program reference

Contents	Description
000xxxxx	Disable program step
001xxxxx	Absolute time
010xxxxx	Wake up time 1 + relative time
011xxxxx	Go to bed time 1 + relative time
100xxxxx	Wake up time 2 + relative time
101xxxxx	Go to bed time 2 + relative time
110xxxxx	Sunrise + relative time
111xxxxx	Sunset + relative time



xxx01111	Rel. time = 3h45min
...	
xxx00001	Rel. time = 15min
xxx00000	Rel. time = 0
xxx11111	Rel. time = -15min
...	
xxx10000	Rel. time = -4h

DATABYTE4 = Program step month & four least significant bits of day

<i>Contents</i>	<i>Description</i>
xxxx0000	Weekly program
xxxx0001	January
xxxx0010	February
xxxx0011	March
xxxx0100	April
xxxx0101	May
xxxx0110	June
xxxx0111	July
xxxx1000	August
xxxx1001	September
xxxx1010	October
xxxx1011	November
xxxx1100	December
xxxx1101	Monthly program
xxxx1110	Monthly program
xxxx1111	Monthly program

<i>Contents byte6</i>	<i>Contents byte4</i>	<i>Description</i>
00xxxxxx	0000xxxx	Never
00xxxxxx	0001xxxx	Day 1 of the month
00xxxxxx	0010xxxx	Day 2 of the month
...	...	...
01xxxxxx	1111xxxx	Day 31 of the month
10xxxxxx	0000xxxx	Never
10xxxxxx	0001xxxx	Every Monday
10xxxxxx	0010xxxx	Every Tuesday
...	...	...
10xxxxxx	0111xxxx	Every Sunday
10xxxxxx	1000xxxx	Every weekend (sa & su)
10xxxxxx	1001xxxx	Every working day (mo...fr)
10xxxxxx	1010xxxx	Every day except Sunday
10xxxxxx	1011xxxx	Every day
10xxxxxx	1100xxxx	Never
...	...	...
11xxxxxx	1111xxxx	Never

DATABYTE5 = Program step hour & group number

<i>Contents</i>	<i>Description</i>
xxx00000	0h
xxx00001	1h
...	...
xxx10111	23h
xx1xxxxx	Program group 1 (Summer program)
x1xxxxxx	Program group 2 (Winter program)
1xxxxxxx	Program group 3 (Holiday program)

DATABYTE6 = Program step minute & msb of day & every flag

<i>Contents</i>	<i>Description</i>
xx000000	0min
xx000001	1min
...	...

xx111011	59min
----------	-------

<i>Contents byte6</i>	<i>Contents byte4</i>	<i>Description</i>
00xxxxxx	0000xxxx	Never
00xxxxxx	0001xxxx	Day 1of the month
00xxxxxx	0010xxxx	Day 2of the month
...	...	...
01xxxxxx	1111xxxx	Day 31of the month
10xxxxxx	0000xxxx	Never
10xxxxxx	0001xxxx	Every Monday
10xxxxxx	0010xxxx	Every Tuesday
...	...	...
10xxxxxx	0111xxxx	Every Sunday
10xxxxxx	1000xxxx	Every weekend (sa & su)
10xxxxxx	1001xxxx	Every working day (mo...fr)
10xxxxxx	1010xxxx	Every day except Sunday
10xxxxxx	1011xxxx	Every day
10xxxxxx	1100xxxx	Never
...	...	...
11xxxxxx	1111xxxx	Never

DATABYTE7 = Program step action

<b>Contents</b>	<b>Action</b>
0	0s25 Pulse
1	1s Pulse
2	2s Pulse
...	...
119	1min59s Pulse
120	2min Pulse
121	2min15s Pulse
...	...
131	4min45s Pulse
132	5min Pulse
133	5min30s Pulse
...	...
181	29min30s Pulse
182	30min Pulse
183	31min Pulse
...	...
211	59min Pulse
212	1h Pulse
213	1h15min Pulse
...	...
227	4h45min Pulse
228	5h Pulse
229	5h30min Pulse
...	...
237	9h30min Pulse
238	10h Pulse
239	11h Pulse
...	...
246	18h Pulse
247	Press
248	Long Press
249	Release
250	Lock
251	Unlock
252	Sensor: Safe mode
253	Sensor: Night mode
254	Sensor: Day mode
255	Sensor: Comfort mode

DATABYTE8 = Channel

Contents	Channel
1	Channel 1 or temperature sensor
2	Channel 2
...	...
7	Channel 7
8	Channel 8

## Memory map:

<i>Address</i>	<i>Contents</i>	<i>Address</i>	<i>Contents</i>
H'0000'	Channel 1 name character 1	H'0001'	Channel 1 name character 2
...	...	...	...
H'000E'	Channel 1 name character 15	H'000F'	Channel 1 name character 16
H'0010'	Channel 1 reaction time	H'0011'	Channel 1 start function
H'0012'	Channel 1 end function	H'0013'	Channel 1 mode
H'0014'	Channel 2 name character 1	H'0015'	Channel 2 name character 2
...	...	...	...
H'0022'	Channel 2 name character 15	H'0023'	Channel 2 name character 16
H'0024'	Channel 2 reaction time	H'0025'	Channel 2 start function
H'0026'	Channel 2 end function	H'0027'	Channel 2 mode
...	...	...	...
H'008C'	Channel 8 name character 1	H'0089'	Channel 8 name character 2
...	...	...	...
H'009A'	Channel 8 name character 15	H'009B'	Channel 8 name character 16
H'009C'	Channel 8 reaction time	H'009D'	Channel 8 start function
H'009E'	Channel 8 end function	H'009F'	Channel 8 mode
H'00A0'	Long pressed delay	H'00A1'	Dual function long pressed time
H'00A2'	Led backlight intensity	H'00A3'	Led intensity
H'00A4'	Alarm clock configuration	H'00A5'	Wake up 1 hour (0...23)
H'00A6'	Wake up 1 minutes (0...59)	H'00A7'	Go to bed 1 hour (0...23)
H'00A8'	Go to bed 1 minutes (0...59)	H'00A9'	Wake up 2 hour (0...23)
H'00AA'	Wake up 2 minutes (0...59)	H'00AB'	Go to bed 2 hour (0...23)
H'00AC'	Go to bed 2 minutes (0...59)	H'00AD'	Sunrise hour at 21 December (0...23)
H'00AE'	Sunrise minutes at 21 December (0...59)	H'00AF'	Sunrise 21 January – sunrise 5 January (-128'..127')
H'00B0'	Sunrise 5 February – sunrise 21 January (-128'..127')	H'00B1'	Sunrise 21 February – sunrise 5 February (-128'..127')
H'00B2'	Sunrise 5 March – sunrise 21 February (-128'..127')	H'00B3'	Sunrise 21 March – sunrise 5 March (-128'..127')
H'00B4'	Sunrise 5 April – sunrise 21 March (-128'..127')	H'00B5'	Sunrise 21 April – sunrise 5 April (-128'..127')
H'00B6'	Sunrise 5 May – sunrise 21 April (-128'..127')	H'00B7'	Sunrise 21 May – sunrise 5 May (-128'..127')
H'00B8'	Sunrise 5 June – sunrise 21 May (-128'..127')	H'00B9'	Sunrise 21 June – sunrise 5 June (-128'..127')
H'00BA'	Sunrise 5 July – sunrise 21 June (-128'..127')	H'00BB'	Sunrise 21 July – sunrise 5 July (-128'..127')
H'00BC'	Sunrise 5 August – sunrise 21 July (-128'..127')	H'00BD'	Sunrise 21 August – sunrise 5 August (-128'..127')
H'00BE'	Sunrise 5 September – sunrise 21 August (-128'..127')	H'00BF'	Sunrise 21 September – sunrise 5 September (-128'..127')
H'00C0'	Sunrise 5 October – sunrise 21 September (-128'..127')	H'00C1'	Sunrise 21 October – sunrise 5 October (-128'..127')
H'00C2'	Sunrise 5 November – sunrise 21 October (-128'..127')	H'00C3'	Sunrise 21 November – sunrise 5 November (-128'..127')
H'00C4'	Sunrise 5 December – sunrise 21 November (-128'..127')	H'00C5'	Sunrise 21 December – sunrise 5 December (-128'..127')
H'00C6'	Sunrise 5 January – sunrise 21 December (-128'..127')	H'00C7'	Sunset hour at 21 December (0...23)
H'00C8'	Sunset minutes at 21 December (0...59)	H'00C9'	Sunset 21 January – sunrise 5 January (-128'..127')
H'00CA'	Sunset 5 February – sunrise 21 January (-128'..127')	H'00CB'	Sunset 21 February – sunrise 5 February (-128'..127')
H'00CC'	Sunset 5 March – sunrise 21 February (-128'..127')	H'00CD'	Sunset 21 March – sunrise 5 March (-128'..127')
H'00CE'	Sunset 5 April – sunrise 21 March (-128'..127')	H'00CF'	Sunset 21 April – sunrise 5 April (-128'..127')
H'00D0'	Sunset 5 May – sunrise 21 April (-128'..127')	H'00D1'	Sunset 21 May – sunrise 5 May (-128'..127')
H'00D2'	Sunset 5 June – sunrise 21 May (-128'..127')	H'00D3'	Sunset 21 June – sunrise 5 June (-128'..127')
H'00D4'	Sunset 5 July – sunrise 21 June (-128'..127')	H'00D5'	Sunset 21 July – sunrise 5 July (-128'..127')
H'00D6'	Sunset 5 August – sunrise 21 July (-128'..127')	H'00D7'	Sunset 21 August – sunrise 5 August (-128'..127')
H'00D8'	Sunset 5 September – sunrise 21 August (-128'..127')	H'00D9'	Sunset 21 September – sunrise 5 September (-128'..127')
H'00DA'	Sunset 5 October – sunrise 21 September (-128'..127')	H'00DB'	Sunset 21 October – sunrise 5 October (-128'..127')
H'00DC'	Sunset 5 November – sunrise 21 October (-128'..127')	H'00DC'	Sunset 21 November – sunrise 5 November (-128'..127')
H'00DE'	Sunset 5 December – sunrise 21 November (-128'..127')	H'00DF'	Sunset 21 December – sunrise 5 December (-128'..127')
H'00E0'	Sunset 5 January – sunrise 21 December (-128'..127')	H'00E1'	Sensor name character 1
H'00E2'	Sensor name character 2	H'00E3'	Sensor name character 3
...	...	...	...
H'00F0'	Sensor name character 16	H'00F1'	Temp. sensor: zone
H'00F2'	Temp. sensor: flags	H'00F3'	Temp. sensor: calibration offset
H'00F4'	Temp. sensor: calibration gain	H'00F5'	Temp. sensor: hysteresis
H'00F6'	Temp. sensor: boost difference	H'00F7'	Temp. sensor: Pump delayed on
H'00F8'	Temp. sensor: pump delayed off	H'00F9'	Temp. sensor: min switching time
H'00FA'	Temp. sensor: default sleep time low byte	H'00FB'	Temp. sensor: default sleep time high byte
H'00FC'	Temp. sensor: heater lower temperature range	H'00FD'	Temp. sensor: heater upper temperature range
H'00FE'	Temp. sensor: heater safe temperature set	H'00FF'	Temp. sensor: heater night temperature set
H'0100'	Temp. sensor: heater day temperature set	H'0101'	Temp. sensor: heater comfort temperature set
H'0102'	Temp. sensor: cooler lower temperature range	H'0103'	Temp. sensor: cooler upper temperature range
H'0104'	Temp. sensor: cooler safe temperature set	H'0105'	Temp. sensor: cooler night temperature set
H'0106'	Temp. sensor: cooler day temperature set	H'0107'	Temp. sensor: cooler comfort temperature set
H'0108'	Temp. sensor: alarm 1 temperature set	H'0109'	Temp. sensor: alarm 2 temperature set

H'010A'	Temp. sensor: alarm 3 temperature set	H'010B'	Temp. sensor: alarm 4 temperature set
H'010C'	Module settings	H'010D'	Not used
H'010E'	Not used	H'010F'	Not used

**Remark:**

Unused locations contain H'FF'

**Valid reaction times**

<i>Contents</i>	<i>Reaction time</i>
H'01'	immediatly (default)
H'4C'	1s
H'99'	2s
H'E0'	3s
H'FF'	Channel disabled

**Channel x start/end function**

<i>Contents</i>	<i>Function</i>
1	Channel 1 (default)
2	Channel 2 (default)
...	...
7	Channel 7 (default)
8	Channel 8 (default)

**Remark:**

For a normal one function button, the start and end function channel are the same.

For a multi function button, the start function channel must be less than the end function. At every press the next channel will be send. When the end function channel is reached, the start channel will be send again at the next press.

For a dual function button, the start function channel will be send at a short press or the end function will be send at a long press.

**Channels mode**

<i>Contents</i>	<i>Description</i>
B'xxxxxxx0'	Dual function disabled (default)
B'xxxxxxx1'	Dual function enabled
B'xxxxxx0x'	Multi-function auto reset disabled (default)
B'xxxxxx1x'	Multi-function auto reset enabled
B'xxxx0xx'	Led backlight off
B'xxxx1xx'	Led backlight on
B'xxx0xxx'	Led feedback off (default)
B'xxx1xxx'	Led feedback on (default)
B'xx0xxxx'	Slow blinking led feedback off
B'xx1xxxx'	Slow blinking led feedback on (default)
B'x0xxxxx'	Fast blinking led feedback off
B'x1xxxxx'	Fast blinking led feedback on (default)
B'x0xxxxx'	Very fast blinking led feedback off
B'x1xxxxx'	Very fast blinking led feedback on (default)

**Remark:**

When auto reset is enabled, the start function will be loaded again after 3 seconds inactivity of the channel.

For a dual function button, the start function channel will be send at a short press or the end function will be send at a long press.

The dual function overwrites the multi-function mode.

**Valid long pressed delay**

<i>Contents</i>	<i>Reaction time</i>
H'40'	0.8s (default)
H'80'	1.6s

**Valid dual function long pressed times**

<i>Contents</i>	<i>Long pressed time</i>
H'4C'	1s
H'99'	2s (default)
H'E0'	3s

**Led backlight intensity**

<i>Contents</i>	<i>Led backlight intensity</i>
H'01'	Minimum
...	...
H'05'	default
...	...
H'0F'	Maximum

**Led intensity**

<i>Contents</i>	<i>Led intensity</i>
H'10'	Minimum
...	...
H'29'	Maximum (default)

**Alarm clock configuration**

<i>Contents</i>	<i>Channel locked/unlocked</i>
B'xxxxxxx0'	Alarm 1 disabled (default)
B'xxxxxxx1'	Alarm 1 enabled
B'0xxxxx0x'	Local alarm 1 (default)
B'1xxxxx1x'	Global alarm 1
B'xxxxx0xx'	Alarm 2 disabled (default)
B'xxxxx1xx'	Alarm 2 enabled
B'xxxx0xxx'	Local alarm 2 (default)
B'xxxx1xxx'	Global alarm 2
B'xxx0xxxx'	Sunrise disabled
B'xxx1xxxx'	Sunrise enabled (default)
B'xx0xxxxx'	Sunset disabled
B'xx1xxxxx'	Sunset enabled (default)
B'x0xxxxxx'	Day light savings disabled
B'x1xxxxxx'	Day light savings enabled (default)

**Module settings**

<i>Contents</i>	<i>Description</i>
B'x0xxxxxx'	Keybeep off
B'x1xxxxxx'	Keybeep enabled (default)

**Temp. sensor zone**

<i>Contents</i>	<i>Zone</i>
0'	No zone
1.	Zone 1...
...	...
7	Zone 7

**Temp. sensor flags**

Contents	Description
B'xxxxxxx0'	Pump unjamming disabled (default)
B'xxxxxxx1'	Pump unjamming enabled
B'xxxxxx0x'	Heater valve unjamming disabled (default)
B'xxxxxx1x'	Heater valve unjamming enabled
B'xxxxx0xx'	Temperature alarms absolute (default)
B'xxxxx1xx'	Temperature alarms relative
B'xxxx0xxx'	Low temperature alarm 1 & 2
B'xxxx1xxx'	High temperature alarm 1 & 2(default)
B'xxx0xxxx'	Low temperature alarm 3 & 4
B'xxx1xxxx'	High temperature alarm 3 & 4(default)
B'xx0xxxxx'	Independent temperature alarms (default)
B'xx1xxxxx'	Dependent temperature alarms
B'x0xxxxxx'	Normal Led indication (default)
B'x1xxxxxx'	Thermostat Led indication for VMBGP4
B'0xxxxxxx'	Button 4 of VMBGP4 operates normal (default)
B'1xxxxxxx'	Button 4 of VMBGP4 as manual thermostat control

**Temp. sensor calibration offset (resolution 0.5°):**

Contents	Calibration offset
00001111	Calibration offset +7.5°C
...	...
00000001	Calibration offset +0.5°C
00000000	Calibration offset +0°C (default)
11111111	Calibration offset -0.5°C
...	...
11110000	Calibration offset -8°C

**Temp. sensor calibration gain:**

Contents	Calibration gain
0	Calibration gain
...	...
128	Calibration gain (default)
...	...
255	Calibration gain

Calibrated Temperature = (gain/128) \* sensortemperature + offset

**Temp. sensor hysteresis (resolution 0.5°):**

Contents	Hysteresis
00011111	15.5°C
...	...
00000001	0.5°C
00000000	0°C

**Temp. sensor boost difference (resolution 0.5°):**

Contents	Temperature difference
00010100	+10°C
...	...
00000001	+0.5°C
00000000	0°C
11111111	-0.5°C
...	...
11101100	-10°C

**Temp. sensor pump delayed on, pump delayed off & valve minimum switching time:**

Contents	Time
00000000	0
00000001	1 sec
00000010	2 sec
...	...
11111110	254 sec
11111111	255 sec

**Temp. sensor default sleep time into minutes**

valid range H'0001' to H'FEFF' or 1min to 65.279min

**Temp. sensor lower, upper, safe, night, day, comfort or alarm set (resolution 0.5°):**

Contents	Temperature set
01111000	60°C
00101000	20°C
00000010	1°C
00000001	0.5°C
00000000	0°C
11111111	-0.5°C
11000000	-32°C



<b>Address</b>	<b>Contents</b>	<b>Address</b>	<b>Contents</b>
H'0110'	Linked Push button 1 module address	H'0111'	Linked Push button 1 bit number
H'0112'	Linked Push button 1 action	H'0113'	Linked Push button 1 time parameter
H'0114'	Linked Push button 1 channel parameter	H'0115'	Linked Push button 2 module address
H'0116'	Linked Push button 2 bit number	H'0117'	Linked Push button 2 action
H'0118'	Linked Push button 2 time parameter	H'0119'	Linked Push button 2 channel parameter
H'011A'	...	H'011B'	...
...	...	...	...
H'01FA'	...	H'01FB'	Linked Push button 48 module address
H'01FC'	Linked Push button 48 bit number	H'01FD'	Linked Push button 48 action
H'01FE'	Linked Push button 48 time parameter	H'01FF'	Linked Push button 48 channel parameter

**Remark:** Unused locations contain H'FF'

#### Action

<b>Action number</b>	<b>Action</b>	<b>Time parameter</b>	<b>Channel parameter</b>
0	Switch status led indication	-	Channel number (1...8)
1	Lock channel at closed switch	-	Channel number (1...8)
2	Lock channel at opened switch	-	Channel number (1...8)
3	Lock channel	Timeout	Channel number (1...8)
4	Lock/unlock channel	Timeout	Channel number (1...8)
5	Unlock channel	-	Channel number (1...8)
6	Disable channel program at closed switch	-	Channel number (1...8)
7	Disable channel program at opened switch	-	Channel number (1...8)
8	Disable channel program channel	Timeout	Channel number (1...8)
9	Disable/enable channel program	Timeout	Channel number (1...8)
10	Enable channel program	-	Channel number (1...8)
11	Select no programs	-	-
12	Select summer programs	-	-
13	Select winter programs	-	-
14	Select holiday programs	-	-
15	Enable Alarm 1 at closed switch	-	-
16	Enable Alarm 1 at open switch	-	-
17	Disable Alarm 1 at closed switch	-	-
18	Disable Alarm 1 at open switch	-	-
19	Enable Alarm 1	-	-
20	Enable/Disable Alarm 1	-	-
21	Disable Alarm 1	-	-
22	Enable Alarm 2 at closed switch	-	-
23	Enable Alarm 2 at open switch	-	-
24	Disable Alarm 2 at closed switch	-	-
25	Disable Alarm 2 at open switch	-	-
26	Enable Alarm 2	-	-
27	Enable/Disable Alarm 2	-	-
28	Disable Alarm 2	-	-
29	Enable Sunrise at closed switch	-	-
30	Enable Sunrise at open switch	-	-
31	Disable Sunrise at closed switch	-	-
32	Disable Sunrise at open switch	-	-
33	Enable Sunrise	-	-
34	Enable/Disable Sunrise	-	-
35	Disable Sunrise	-	-
36	Enable Sunset at closed switch	-	-
37	Enable Sunset at open switch	-	-
38	Disable Sunset at closed switch	-	-
39	Disable Sunset at open switch	-	-
40	Enable Sunset	-	-
41	Enable/Disable Sunset	-	-
42	Disable Sunset	-	-
43	Sensor: Comfort mode	Short press sleep time	Long press sleep time
44	Sensor: Day mode	Short press sleep time	Short press sleep time
45	Sensor: Night mode	Short press sleep time	Short press sleep time
46	Sensor: Safe mode	Short press sleep time	Short press sleep time
47	Sensor: Heating mode	-	-
48	Sensor: Cooling mode	-	-
49	Sensor: Forced Safe mode at open switch	-	0xFF

50	Sensor: Forced Safe mode at closed switch	-	0xFF
51	Sensor: Forced Safe mode	Timeout	-
52	Sensor: Forced or Cancel Forced Safe mode	Timeout	-
53	Sensor: Cancel Forced Safe mode	-	-

Time parameter

Time parameter	Timeout
0	0s (no timer)
1	1s
2	2s
3	3s
...	
119	1min59s
120	2min
121	2min15s
...	
131	4min45s
132	5min
133	5min30s
...	
181	29min30s
182	30min
183	31min
...	
211	59min
212	1h
213	1h15min
...	
227	4h45min
228	5h
229	5h30min
...	
237	9h30min
238	10h
239	11h
...	
251	23h
252	1d
253	2d
254	3d
255	Infinite

Sleep time parameter	action
0	No action
1	Select until next program step execution
2	Select for default sleep time (see sensor config.)
3	Select for 15 min (auto return to program)
4	Select for 30 min (auto return to program)
...	...
17	Select for 3h45 min (auto return to program)
18	Select for 4h min (auto return to program)
19	Select for 4h30 min (auto return to program)
...	...
33	Select for 11h30 min (auto return to program)
34	Select for 12h (auto return to program)
35	Select for 13h (auto return to program)
...	...
45	Select for 23h (auto return to program)
46	Select for 1 day (auto return to program)
47	Select for 1 day 12h (auto return to program)
...	...
57	Select for 6 days 12h (auto return to program)
58	Select for 7 days (auto return to program)
59	Select for 8 days (auto return to program)
...	...
96	Select for 45 days (auto return to program)
97	Select and ignore all program steps

<i>Address</i>	<i>Contents</i>	<i>Address</i>	<i>Contents</i>
H'0200'	Program step 1 byte1	H'0201'	Program step 1 byte2
H'0202'	Program step 1 byte3	H'0203'	Program step 1 byte4
H'0204'	Program step 1 byte5	H'0205'	Program step 1 byte6
...	..	..	..
H'03F8'	Program step 85 byte1	H'03F9'	Program step 85 byte2
H'03FA'	Program step 85 byte3	H'03FB'	Program step 85 byte4
H'03FC'	Program step 85 byte5	H'03FD'	Program step 85 byte6
H'03FE'	Not used	H'03FF'	Not used

<i>Contents program byte1</i>	<i>Description</i>
B'000xxxxx'	Disable program step
B'001xxxxx'	Absolute time
B'010xxxxx'	Wake up time 1 + relative time
B'011xxxxx'	Go to bed time 1 + relative time
B'100xxxxx'	Wake up time 2 + relative time
B'101xxxxx'	Go to bed time 2 + relative time
B'110xxxxx'	Sunrise + relative time
B'111xxxxx'	Sunset + relative time
B'xxx01111'	Rel. time = 3h45min
...	
B'xxx00001'	Rel. time = 15min
B'xxx00000'	Rel. time = 0
B'xxx11111'	Rel. time = -15min
...	
B'xxx10000'	Rel. time = -4h

**Remark:** Wake up, Go to bed, sunrise & sunset time are only allowed for weekly programs

<i>Contents program byte2</i>	<i>Description</i>
B'xxxx0000'	Weekly program
B'xxxx0001'	January
B'xxxx0010'	February
B'xxxx0011'	March
B'xxxx0100'	April
B'xxxx0101'	May
B'xxxx0110'	June
B'xxxx0111'	July
B'xxxx1000'	August
B'xxxx1001'	September
B'xxxx1010'	October
B'xxxx1011'	November
B'xxxx1100'	December
B'xxxx1101'	Monthly program
B'xxxx1110'	Monthly program
B'xxxx1111'	Monthly program

<i>Contents program byte3</i>	<i>Description</i>
B'xxx00000'	0h
B'xxx00001'	1h
...	...
B'xxx10111'	23h
B'xx1xxxxx'	Program group 1 (Summer program)
B'x1xxxxxx'	Program group 2 (Winter program)
B'1xxxxxxx'	Program group 3 (Holiday program)

<i>Contents program byte4</i>	<i>Description</i>
B'xx000000'	0min
B'xx000001'	1min
...	...
B'xx111011'	59min

<i>Contents program byte4</i>	<i>Contents program byte2</i>	<i>Description</i>
B'00xxxxxx'	B'0000xxxx'	Never
B'00xxxxxx'	B'0001xxxx'	Day 1 of the month
B'00xxxxxx'	B'0010xxxx'	Day 2 of the month
...	...	...
B'01xxxxxx'	B'1111xxxx'	Day 31 of the month
B'10xxxxxx'	B'0000xxxx'	Never
B'10xxxxxx'	B'0001xxxx'	Every Monday
B'10xxxxxx'	B'0010xxxx'	Every Tuesday
...	...	...
B'10xxxxxx'	B'0111xxxx'	Every Sunday
B'10xxxxxx'	B'1000xxxx'	Every weekend (sa & su)
B'10xxxxxx'	B'1001xxxx'	Every working day (mo...fr)
B'10xxxxxx'	B'1010xxxx'	Every day except Sunday
B'10xxxxxx'	B'1011xxxx'	Every day
B'10xxxxxx'	B'1100xxxx'	Never
...	...	...
B'11xxxxxx'	B'1111xxxx'	Never

<i>Contents program byte5</i>	<b>Action</b>
0	0s25 Pulse
1	1s Pulse
2	2s Pulse
...	...
119	1min59s Pulse
120	2min Pulse
121	2min15s Pulse
...	...
131	4min45s Pulse
132	5min Pulse
133	5min30s Pulse
...	...
181	29min30s Pulse
182	30min Pulse
183	31min Pulse
...	...
211	59min Pulse
212	1h Pulse
213	1h15min Pulse
...	...
227	4h45min Pulse
228	5h Pulse
229	5h30min Pulse
...	...
237	9h30min Pulse
238	10h Pulse
239	11h Pulse
...	...
246	18h Pulse
247	Press
248	Long Press
249	Release
250	Lock
251	Unlock
252	Sensor: Safe mode
253	Sensor: Night mode
254	Sensor: Day mode
255	Sensor: Comfort mode

<i>Contents program byte6</i>	<b>Channel</b>
1	Channel 1
2	Channel 2
..	...
7	Channel 7
8	Channel 8
128	Temperature sensor