



velleman



- Buzzer / Summer / Zumbador
12VDC (100mA max.)
- Speaker / luidspreker / haut-parleur / lautsprecher / altavoz
- Digital output / Digitale uitgang / Sortie numérique / Digitalausgang / Salida digital 5VDC (50mA max.)
- Analog output / Analoge uitgang / Sortie analogique / Analogausgang / Salida analógica 0...5VDC (5mA max.)
- Power supply / Voedingsspanning / Alimentation / Spannungsversorgung / Alimentacion 12VDC (200mA max.)



Digital out trigger distance adjust / afstandsregeling trigger digitale uitgang / Réglage de distance pour le déclenchement de la sortie numérique / Regelung Trigger-Abstand mit digitalem Ausgang / Ajuste de la distancia para catalizador de salida digital



'Digital out active'- indicator / 'Digitale uitgang actief'-indicator / Témoin 'Sortie numérique active' / Anzeige 'digitaler Ausgang aktiv' / Indicador de 'salida digital activa'

Analog led-bar / Analoge led-uitteizing / Affichage LED analogique / Analoge LED-Leiste / Barra con LEDs analógicos